


Instrucciones de montaje
Installation Instructions
Notice d'installation
Istruzioni per il montaggio
Montageanweisung
Montagehandleiding


Montagevejledning
Οδηγίες εγκατάστασης
Instruções de montagem
Monteringsanvisning
Asennusohje
Návod k montáži

Paigaldusjuhend
Szerelési utasítás
Montāžas instrukcija
Montavimo instrukcija
Instrukcja montażu
Navodila za montažo


Návod na montáž
Монтажни инструкции
Instrucţiuni de montaj
Инструкция по монтажу
安装说明





SV/SVT



SX/SXT



SL/SLT

	A	B	C	D	E	F	G			M25	M25/M40
SV/SX/SL111	119	119	68	108	108	61	61	7	-	7	-
SV/SX/SL161	176	130	76	162	116	114	69	6	4	6	4
SV/SX/SL171	189	165	95	175	151	127	101	6	4	6	4
SV/SX/SLL231	255	194	95	241	180	194	132	4	6	4	6
SV/SX/SLL322	342	253	129	328	239	264	183	-	12	-	12
SMV/SMX/SML171	189	165	155	175	151	127	101	6	4	6	4
SMV/SMX/SML231	255	194	175	241	180	194	132	4	6	4	6
SMV/SMX/SML322	342	253	188	328	239	264	183	-	12	-	12

